

Updating your MyWay Navigator to Tracker Hunter

Tracker has released a new mobile software product for GPS dog tracking. Now you have a chance to download Tracker Hunter (TH) and replace your MyWay Navigator (MWN) with it.


If the GPS collar you are tracking is Tracker 310i or Tracker G400 (available only in Scandinavia), you can start using GPRS tracking (called Tracker Live service) with Tracker Hunter.

NOTE! Check the list of compatible phones from our website (Tracker Hunter product page > Specification). GPRS tracking requires a subscription (SIM-card) with data plan for both the collar and the mobile phone.

To update from MyWay Navigator to Tracker Hunter you will need to take a back-up copy of MWN, then remove MWN and download TH.

Here is how it happens:

1. You will need:
 1. MyWay Navigator registration code, which is on a sticker in the package MWN was sold to you or has been delivered you by other means, such as email. (Note: you need the code just in case – If everything goes well in the updating process, the code will not be needed.)
 2. A computer with PC-suite software and a connection between the computer and your phone in order to make a back-up copy of MWN. The back-up can also be made without a computer, see [c](#)).
2. Take a back-up of the myway-folder from your mobile phone memory card.
 - myway-folder includes all MWN maps, targets and waypoints. If something goes wrong with the updating, you can return the data of MWN back to your memory card. [a](#))
 - To take the back-up, use PC-Suite software on your computer.[b](#)), [c](#)).
 1. Connect your phone to the computer with a cable or via Bluetooth.
 2. Start PC-Suite and go to File manager
 3. Open the memory card
 4. Copy the folder named myway from the memory card to your computer.
3. Remove MyWay Navigator from your mobile phone
 - Go to the MyWay Navigator icon on the main menu and press C
 - When you remove MyWay Navigator, the folder "myway" is not removed from the memory card. DO NOT REMOVE IT, because Tracker Hunter will get all MWN data from that folder.

4. If you want to update the software of your mobile phone, you can do it in this phase. Follow the instructions given by the manufacturer of the phone. If you do not want to update the phone, proceed with TH installation:
5. Download Tracker Hunter to your phone:
 1. Send HUNTER in an SMS to the number +358400112236 from your mobile phone. The charge will be the normal cost of a text message.
 2. After a short time, you will receive a reply message with a link for downloading the application. When you receive the message, follow the link and the Internet browser on the mobile phone will open to it. Make sure your automatic search is on (see the user's manual of your mobile phone for more information on automatic searching). Please note: If you do not get a reply to your SMS message rather quickly, you may access the installation page at <http://service.tracker.fi/hunter> by using the mobile phone's browser.
 3. Click on the Tracker Hunter link to start the installation. Please note that there may be several installation links on the site.
 4. Choose your memory card as the desired location for the installation, and answer yes to all questions.
 5. If you desire compatibility with older tracking devices or software, you also need to install the Telematic Proxy software (supported only by Symbian S60 3G phones).
 6. Close the Internet browser on your mobile phone when the installation is complete.
 7. DO NOT START THE APPLICATION before you have successfully completed the next phase, Phone settings.
2. Phone settings
 1. For Nokia phones the settings are done via the Application Manager or Manager function. Choose the Tracker Hunter application from the Application Manager list, and enter the required settings. The location of the application manager varies with the phone model, but the icon is always the same . For instance, on the N73 phone the menu option is > Tools > Application manager, and on the 6110 Navigator the option is . > Settings > Data manager > App. manager. Choose the Hunter application from the list, and adjust the settings as described below. Please note: The location of the settings varies in different phone models. For instance, N73 users should choose Options > Suite settings and 6110 Navigator users should select Options > Open.

2. For Sony Ericsson phones, the settings are usually requested when you start the software for the first time.
3. Tracker Hunter requires the following security settings:
 - a. Network Access: Always allowed
 - b. Messaging: Ask every time
 - c. App. Auto-Start: Ask first time
 - d. Connectivity: Always allowed
 - e. Read User Data: Always allowed
 - f. Edit User Data: Always allowed
 - g. Positioning: Always allowed (mobiles with integrated GPS)

6. Starting up and registering Tracker Hunter

NOTE! When starting up for the first time, data from myway-folder is transferred to Tracker Hunter. This may take up to several hours. Make sure you do not receive any phone calls and that the phone is plugged in to the charger for this phase. The copying occurs only when starting up the software for the first time.

1. Activate the Bluetooth connection on your mobile phone (see the user's manual for your phone for more information on the Bluetooth connection).
 2. Start the software by clicking on the Tracker Hunter icon
 3. The starting up will proceed for a moment, followed by text "MyWay Navigator -> Tracker Hunter". This is when data from myway-folder is transferred to Tracker Hunter. **Wait patiently for this phase to end.**
 4. After this the installation is ready.
7. Tracker Hunter instructions can be found in the software. Additionally, TH Installation instruction (in the package or on Tracker website, under Tracker Hunter) gives you basic information of using the software, such as starting up Tracker Live.
8. We recommend that you take a back-up copy of hunter-folder from the memory card to your computer the same way MWN back-up was instructed in this document.

a) Tracker Oy is not responsible for any loss of maps, targets, lines, tracks and routes caused by errors in the mobile phone or mistakes by the user.

b) Do not use memory card reader to take the back-up copy, because it does not make a difference between capital letters and lower case letters and therefore prevents the back-up copy from functioning.

c) Another option of taking the back-up copy is to copy the myway-folder to another place on your memory card. Go to file management on your mobile phone and choose memory card. Create a folder and name it for example "back-up". Then choose myway-folder on the memory card and copy it to the back-up folder. This is not as safe a system for making the back-up copy as is the one with the computer, because in case the memory is damaged, all data will be lost.

Back to MyWay Navigator from Tracker Hunter

If for some reason you want to go back to using MyWay Navigator instead of Tracker Hunter, do as follows:

1. Restore the myway-folder to your mobile phone memory card.
2. Remove Tracker Hunter from your mobile phone.
3. Install MyWay Navigator.

All phases are done the same way they were done the other way round. Note that this restores the MWN with the content it had when you took the back-up copy of the myway-folder.